AWARNING:

This must be installed by qualified personnel. Read all instructions thoroughly. Place machine on level surface. Turn off and unplug batteries. Remove key from machine.

PARTS IN KIT:

ltem	P/N	Description	Qty
1	8.645-088.0	Hose assembly 1-1/2" ID 10' accessory	1
2	8.600-009.0	Tube 20" Extension	2
3	8.643-749.0	Accessory tool holder	1
4	8.600-239.0	Clamp, 1.75 WORM GEAR X .312	1
5	8.632-751.0	Screw, KA50 X 16 SS WN1412	2
6	9.802-754.0	Screw, 1/4" X 1/2" HH NC, WHIZ LOC	2
7	8.634-487.0	Brush, Dust	1
8	6.903-403.0	Crevice Nozzle DN32	1
9	8.644-335.0	Bracket hose support	1
10	-	Diverter Valve - Assembled	1

TOOLS REQUIRED:

Phillips Screwdriver 1/4" Nut Driver 3/8" Wrench



INSTALLATION INSTRUCTIONS:

Scan QR code to Watch the Installation Video:



Turn off key switch. Remove the two side doors. Turn off main breaker.



Remove the 2" hose from the old diverter valve.



Remove old valve assembly by removing the 5 Phillips flathead screw inside the vacuum box. (Save screws)



Remove the plate blocking the rear hole in the back of the main body.



Feed the non-cuff end of the 1.5" slinky hose (Item 1) through the rear hole in the back of the main body.



Place the hose in the channel in the inside top of the main body and bolt the hose support bracket (Items 6 and 9) into place to hold the hose in the channel.



Install the new valve body assembly (Item 10) in the same manner as the one just removed, using the five screws.



Attach the non-cuff end of the hose (Item 1) to the new valve body assembly (Item 10) with the hose clamp (Item 4).



Plug the connector on the end of the actuator into the main harness connector labeled B-C27.



Assemble the 2" hose from the brush deck hopper to the new valve body in the same manner as it was removed.



Attach the accessory tool holder (Item 3) to the inside of the left door using the two screws (Item 5).



Attach the crevis nozzle tool (Item 8) and dust brush tool Item (Item 7) to the holder.



Place one of the wand tubes (Item 2) in the end of the accessory hose and place the other end into the holster at the back left of the machine.



Place the second wand tube in the adjacent holster. Turn on the main breaker. Replace the two side doors.

Turn the key switch to on position.

Place mode switch into the accessory wand position.



The vacuum will come on. Remove the wand from the holster and start vacuuming.



To attach tools, open the left-side door, remove desired tool, and attach to the end of the wand. Close the door to reactivate the vacuum system.

For long reach, attach the second wand tube and then the desired tool.

Note, the machine will not propel during accessory wand mode. Return everything back to its mounting positions and then press the transport button on the mode switch to transport the machine.